



# STRIKE PLATES


EA306




EA321<sup>\*)</sup>




EA322




EA323<sup>\*)</sup>




EA324




EA325




EA326




EA327




EA328




EA329




EA330




EA331




EA332<sup>\*)</sup>



LP781



LP764<sup>\*)</sup> (for EL532HS)



Nolimal d.o.o.  
 Cesta pod goro 42, 1353 Borovnica, Slovenija  
 tel.: 01/754 83 60, fax: 01/754 83 61,  
 www.nolimal.si; info@nolimal.si

\*) Handing must be defined.